

30W快速充電器
XQZ-UC1



簡介

[功能概覽](#)

[硬體概覽](#)

使用充電器

[充電](#)

法律資訊

[概覽](#)

[FCC Statement \(AC-0540-JP\)](#)

30W快速充電器
XQZ-UC1

功能概覽


30W快速充電器XQZ-UC1能減少支援USB Power Delivery的Xperia裝置的充電時間。

注意

- 使用30W快速充電器XQZ-UC1為裝置充電時，請一律使用購買時隨附於充電器的USB Type-C連接線。

30W快速充電器
XQZ-UC1

硬體概覽




1. USB連接埠
2. USB Type-C連接線

30W快速充電器
XQZ-UC1

充電

使用充電器為裝置充電



- 1 將USB Type-C連接線一端連接至充電器的USB連接埠。
- 2 將充電器插入電源插座。
- 3 將連接線另一端連接裝置的USB連接埠。裝置電池就會開始充電。

裝置完全充電之後，將充電器從電源插座拔除，將連接線平直向外拉，從裝置上拔除。請確定沒有折到接頭。

30W快速充電器
XQZ-UC1

概覽

AC-0540-EU/AC-0540-UK



AC-0540-UK



使用之前，請先閱讀另附的重要資訊小手冊。

本說明指南由Sony Corporation或其當地聯屬公司印製。本說明指南不具任何保固項目。Sony Corporation可能因印刷錯誤、最新資訊有誤或因程式和/或設備改良而隨時對本說明指南進行修改，恕不另行通知。前述更動將納入本說明指南之後續版本。

版權所有。

©2021 Sony Corporation

1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan

Sony Europe B.V.
Da Vincilaan 7-D1, 1930 Zaventem, Belgium

Sony為Sony Corporation的商標或註冊商標。

本文所述之所有產品和公司名稱為其各自所有者的商標或註冊商標。任何未經明示授予的權利均予保留。所有其他商標均屬於其各自所有者的財產。

如需詳細資訊，請造訪<https://www.xperiainfo.com/>。

所有圖片僅供功能說明參考，請以實際配件為準。

30W快速充電器
XQZ-UC1

FCC Statement (AC-0540-JP)

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

“Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.”

Supplier's Declaration of Conformity

Trade Name : Sony

Model : AC-0540-JP

Responsible Party : Sony Electronics Inc.

Address : 16535 Via Esprillo, San Diego, CA 92127 U.S.A.

Telephone Number : 858-942-2230